CAMERA INSTRUCTIONS

QUICK START GUIDE




Download Emanta

Read these instructions carefully before using the camera, and keep them for future reference.

ABOUT THIS PRODUCT

This manual is only a guide for related products and may differ from the actual product, please refer to the actual product. Due to product version upgrade or other needs, this manual may be updated without further notice!

PRODUCT INTRODUCTION




APP DOWNLOAD AND INSTALLATION


Search for “Emanta” in the App Store or Google Play to download the app.

Note: Emanta requires iOS 15.1 or later on Apple devices and Android 7.0 or later on Android devices.

Scan the QR code with your phone to download the Emanta app.



“Add new device”



“+”, then “Add Device”

ADD YOUR CAMERA

Make sure the camera is powered on.

1. Turn on **Wi-Fi** and **Bluetooth** on your phone.
2. Open the **Emanta app** and sign in.
3. Tap **“+”** or **“Add new device”**, then select the camera.
4. Select your home **Wi-Fi network** and enter its **password**.
5. Follow the on-screen instructions and wait for the camera to be added.
6. When the **live view** appears, setup is complete.


If the camera cannot be added:

1. Check that the camera has power and the network is available.
2. Reset the camera, then try adding it again.
3. If the issue persists, contact Emanta customer support.

IN THE BOX

Camera x 1
Power Adapter x 1
Type-C Cable x 1
Screw Pack x 1
Mounting Plate x 1
User Manual x 1


INSTALLATION AND PLACEMENT



▶ Table placement

Place on a desk or table.

▶ Wall installation



Step 1: Mark & Drill

Place card, mark spots, and drill.

Step 2: Fix Plate

Align the holes, insert the anchors, and tighten the screws.

Step 3: Attach Camera

Line up grooves, twist.

COMMON PROBLEMS

Q1: How do I connect the camera to Wi-Fi?

1. Turn on Wi-Fi and Bluetooth on your phone.
2. Download the Emanta app and register with your email address or mobile phone number.
3. Power on the camera and wait for the network configuration prompt.
4. Sign in to the Emanta app. Tap **“+”** or **“Add new device”**, then select the camera.
5. Select your home Wi-Fi network and enter the Wi-Fi password.
6. Wait for the camera to be added, then open **live view**. When the image appears, setup is complete.

Q2: How do I reset the camera?

A2: Turn the head of the camera upwards, then press and hold the **RESET** button (near the neck of the camera) for **5–8 seconds** to reset it.

Q3: Is a microSD card included, and how do I use it?

① A microSD card is not included.

② To insert the card, turn the head of the camera upwards. Note: Please format the microSD card and turn off the power before inserting it.

③ To play back video, open the video interface and tap **“Playback”**, select **“Local Storage”**, then select the video you want to view by time.

Q4: What should I do if the camera appears offline?

A4: The camera was successfully added, but the Emanta app shows the device as offline, which means the app cannot currently connect to the camera. Please check the following:

① Check that the camera’s power supply is normal, that it is plugged in and connected, and that the adapter meets the camera’s power requirements.

Continued on page 7.

Q4: Offline checks (continued)

② Check whether other devices on the same Wi-Fi network can connect to the internet. If none can connect, check your router and home internet connection. If only the camera has a problem, try another network or a mobile hotspot.

③ If a microSD card is inserted in the camera, it can be removed. Incompatible or low-quality microSD cards may cause the device system to crash and go offline.

④ To reset the camera, press and hold the **RESET** button for **5–8 seconds** to restore factory settings, then reconnect it to the Emanta app.

Q5: How do I share the camera with others?

A5: You can share the camera's live view with others. Open the Emanta app and go to **Me → My Shares**. Select the camera and use **Share** to invite another registered user. Follow the on-screen instructions to complete sharing.


Q6: Is the camera compatible with Alexa and Google Home?

A6: This camera is compatible with Alexa only. It is not compatible with Google Home.

Q7: How do I connect the camera to Alexa?

A7: Please follow the steps below:

1. Download the Emanta app and register an account.
2. Open the Alexa app and tap **More** in the lower-right corner.
3. Tap **Skills & Games**, tap the search button in the upper-right corner, and search for **Emanta**.
4. Tap the **Emanta skill** to open the skill details page. Tap **ENABLE TO USE**, then tap **Agree and Link**. You will then return to the Alexa app.
5. Tap **CLOSE**, then tap **DISCOVER DEVICES** to complete the binding.


Certification
QC.: _____
Date: _____

CUSTOMER SERVICE

Warranty

24-month limited warranty

Call Us

United States: +1 (231) 262-5898

9:00 AM–9:00 PM ET, Daily

Email Us

Customer Support:


Cemanta_IoT@outlook.com

Juan IOT Technology (Hong Kong) Co., Limited
Room 3, 16/F, Empress Plaza, 17-19 Chatham Road South,
Tsim Sha Tsui, Kowloon, Hong Kong


Warning



In case of fire or lightning,pls don't put product in damp and raining place,operate or maintain according to the user manual.



Be careful when you see attachment with a Dangerous Voltage which might cause serious electric accident.



Notice:

1. Ensure your equity,pls read the user manual carefully before you use the product.
2. Pls contact professional people if you need install and maintain the product.
3. Working Environment:temperature of -20°C~+60°C, relative humidity under 85%.
4. Pls don't exceed the user manual's standard range of temperature, humidity and voltage.